

Globo

Globo	ref.	a	b	c	d	e
(1) Peanha nº 10 / knob nº 10	-	-	-	61,0±1,0	-	36,0±1,0
(2) Espelho nº 10 / fingerplate nº 10	007600700215	71,0±1,0	6,5±1,0	-	-	-
(3) Peanha nº 10 c/ espelho / knob nº 10 with finger plate	-	71,0±1,0	6,5±1,0	61,0±1,0	41,0±1,0	36,0±1,0

